



Summa Canister Grab Sample Instructions



1. Attach the quick connect grab fitting to the canister. To do this, align the QT Valve stem (male), which is on the canister, with the QT valve body (female).
2. Pull back the sleeve on the QT valve body (female) and insert the stem (male) into the body. Then, release the sleeve. If the two pieces are correctly engaged, you will hear a hissing sound as the can fills.
3. After 45–60 seconds, remove the female fitting from the male fitting.
4. Label the tag on the canister with the sample ID, fill out COC, return the canister and grab fitting to the lab.